








Help	
<b>Symptom:</b> Product Application starts too soon	<b>Solution:</b> Decrease Turn on time
Product Application starts too late	Increase Turn on time
Product Application stops too soon	Decrease Turn off time
Product Application stops too late	Increase Turn off time
<p>NOTE: If more/less overlap is desired, adjust the percent overlap within Overlap Settings.</p> <div style="display: flex; justify-content: space-around; align-items: center;">   </div>	


**A**  Mapping


**F**  GS3


**B**  Guidance


**G**  Resources


**C**  Diagnostics

**H**  Equipment


**D**  Water Mgmt


**I**  Document

**E**  Section


**J**  Totals

7:42am

 1/1



# SWATH CONTROL/SECTION CONTROL Turn ON/OFF Guide



Path to Adjustment: MENU > GS2 or GS3 Pro > "H" Tab > Implement > Swath Control Settings